

To test a smoke detector:

- Press the battery-test button on the unit to make sure the battery is properly connected.
- If the unit has a battery that's more than a year old, replace the battery (see below).

To replace a smoke detector battery:

- Remove the smoke detector cover, typically by carefully pulling down on the case's perimeter or by twisting the case counterclockwise.
- Locate and remove the battery. As needed, replace it with a new one.
- Close the case and test the smoke detector (see above).